



TFT-LCD TV

Chassis	GBP23SEN
	GBP26SEN
	GBP32SEN
	GBP37SEN
	GBP40SEN

Model	LE23R86BD
	LE26R86BD
	LE26R87BD
	LE32R86BD
	LE32R87BD
	LE37R86BD
	LE40R86BD
	LE40R87BD

SERVICE Manual

TFT-LCD TV



Fashion Feature

- Luxurious Slim Design
- Supreme Picture Quality
- Supreme Sound Quality
- Supreme Convenience Quality
- Convenience for Users
- iDTV

Copyright

© 2007 by Samsung Electronics Co., Ltd.

All rights reserved.

This manual may not, in whole or in part, be copied, photocopied, reproduced, translated, or converted to any electronic or machine readable form without prior written permission of Samsung Electronics Co., Ltd.

LE23R86BD/LE26R86BD/LE26R87BD/LE32R87BD/
LE40R86BD/LE40R87BD/LE46R87BD/LE46R86BD
Service Manual

First edition March 2007.

Printed in Korea.

Trademarks

Samsung is the registered trademark of Samsung Electronics Co., Ltd.

LE23R86BD/LE26R86BD/LE26R87BD/LE32R87BD/
LE40R86BD/LE40R87BD/LE46R87BD/LE46R86BD
Service Manual and Macmaster Cable Adapter are
trademarks of Samsung Electronics Co., Ltd.

Macintosh and Power Macintosh are trademarks of
Apple Computer, Inc.

All other trademarks are the property of their respective
owners.

Contents

1. Precautions	1-1
1-1 Safety Precautions	1-1
1-2 Servicing Precautions	1-2
1-3 Static Electricity Precautions	1-2
1-4 Installation Precautions	1-3
2. Product specifications	2-1
2-1 Fashion Feature	2-1
2-2 LE23R86BD Specifications	2-2
2-3 LE26R86BD Specifications	2-3
2-4 LE32R86BD Specifications	2-4
2-5 LE37R86BD Specifications	2-5
2-6 LE40R86BD Specifications	2-6
2-7 Spec Comparison	2-7
2-8 Option Specification	2-8
3. Alignments and Adjustments	3-1
3-1 Service Instruction	3-1
3-2 How to Access Service Mode	3-2
3-3 Factory Data	3-3
3-4 Service Adjustment	3-11
3-5 Software Upgrade	3-14
4. Troubleshooting	4-1
4-1 First Checklist for Troubleshooting	4-1
4-2 Checkpoints by Error Mode	4-2
5. Exploded View and Parts List	5-1
5-1 LE23R86BD Exploded View	5-1
5-2 LE23R86BD Parts list	5-2
5-3 LE26R86BD Exploded View	5-3
5-4 LE26R86BD Parts list	5-4
5-5 LE32R87BD Exploded View	5-5
5-6 LE32R87BD Parts list	5-6
6. Electrical Parts List	6-1
6-1 LE23R86BDX Parts List	6-1
6-2 LE26R86BDX Parts List	6-26
6-3 LE32R87BDX Parts List	6-50
6-4 LE37R86BDX Parts List	6-76
6-5 LE40R86BDX Parts List	6-102

Contents

7. Block Diagram	7-1
8. Wiring Diagram	8-1
8-1 LE23R86BD/LE26R86BD/LE32R86BD/LE37R86BD/LE40R86BD Wiring Diagram	8-1
8-2 Main Board Layout	8-2
8-3 PIN characteristic	8-3
8-4 Connector Location and PCB outline figure	8-6
8-5 Output Connector	8-7
9. Schematic Diagrams	9-1
10. Operating Instructions and Installation	10-1
10-1 Front	10-1
10-2 Viewing the Connection Panel	10-2
10-3 Remote control	10-5
10-4 Installation the Stand	10-6
10-5 Installing the Wall Mount Kit	10-6
11. Disassembly and Reassembly	11-1
11-1 Disassembly	11-1
11-2 Reassembly	11-5
12. PCB Diagram	12-1
12-1 Main PCB Diagram (Without Card Slot)	12-1
12-2 Main PCB Diagram (With Card Slot)	12-2
13. Circuit Descriptions	13-1
13-1 Main Signal Description	13-1
13-2 DTV Signal Description	13-2
13-3 RF/DTV Tuner (DNOS403MH261B(S)) SPEC.	13-3
13-4 DTV MAIN ChipSet	13-9
14. Reference Information	14-1
14-1 Technical Terms	14-1
14-2 Pin Assignments	14-4
14-3 Timing Chart	14-7
14-4 Panel Description	14-11



- This Service Manual is a property of Samsung Electronics Co., Ltd.
Any unauthorized use of Manual can be punished under applicable International and/or domestic law.

Samsung Electronics Co., Ltd.
416, Maetan-3Dong, Yeongtong-Gu, Suwon City,
Gyeonggi-Do, Korea, 443-742
Printed in Korea
P/N : BN82-00183A-00
URL : <http://itself.sec.samsung.co.kr/>